

# Active background reduction methods in low background experiments

---

Connor Hayward

July 26, 2019

IMPRS Young Scientist Workshop 2019, Ringberg Castle



---

Max-Planck-Institut für Physik  
(Werner-Heisenberg-Institut)



---

MAX-PLANCK-GESellschaft

# Why reduce background

$$T_{1/2}^{0\nu} \propto \sqrt{\frac{m \cdot t}{BI \cdot \Delta E}} \text{ with } \begin{cases} m \cdot t & , \quad \text{exposure} \\ BI & , \quad \text{background index} \\ \Delta E & , \quad \text{energy resolution} \end{cases}$$


$\Delta E \rightarrow$  is limited by the detectors

$m \cdot t \rightarrow$  is limited by funding

$BI \rightarrow$  can be improved!

Two ways to reduce: make things clean, active reduction

- Active reduction: add methods to veto background from signal
- Provide tagging for particles from outside
  - Muon veto panels
  - Water tank tags neutrons
- Can also remove background from within: scintillators



**Figure:** Detector layout of GERDA. A) Dectector overview. B) LAr Veto System.  
C) Detector Array. D) Detector holding structure

- Materials that emit light when exposed to ionising radiation
- **Organic (plastics):**
  - Short emission time (ns)
  - Light yield around 10,000 photons / MeV
  - Potentially strong material properties
- **Inorganic (liquid noble gas)**
  - Emission time on order  $\mu\text{s}$
  - Potential for light yield around 30,000 / MeV
  - Cryogenic liquid: cool the inner detectors

# Scintillation Mechanism




Figure: Energy level diagram of a scintillator.

# Liquid Argon Scintillation




Figure: Scintillation mechanism in liquid argon, from <http://darkmatter.ethz.ch/>

# Before liquid argon cuts




Figure: Background spectrum before liquid argon anti-coincidence cut



# After liquid argon cuts





Figure: Background spectrum after liquid argon anti-coincidence cut

- Liquid argon peak emission is VUV, hard to find matching photosensors
- Requires wavelength shifting, more materials, more contamination
- Wavelength shifting shroud efficiency around 30%
- Lots of opaque material near detectors, reducing efficiency

Solution: replace parts of the holding structure with transparent material, ideally scintillating.


Enter: PEN

# What is PEN?




Top: Structural formula of PEN.  
Bottom: Custom molded PEN capsule parts

- Commercially available
- Brandnames: Teonex
- Relatively cheap
- Experience in manufacturing
- Transparent plastic
- Known to scintillate [arXiv:1903.10736]
  - Self-veto?
- PEN as low background material?



Set up used for light yield measurements

- Scintillation yield measured in electron spectrometer  
[doi:10.1088/1748-0221/10/09/P09008]
- Electron energies between 0.4 - 1.6 MeV used
- Compared to a PS, SuperNEMO



PS and PEN light output when excited with mono-energetic electrons  
(FWHM =  $1.0 \pm 0.2$  % at 1 MeV)


- Light yield for PEN around 2/3s of PS
- Lower yield than literature, self produced tiles
- Trade off: cleanliness vs light yield



Set up for emission spectrum


- PEN emits blue light, no extra fluors
- Good match to commercial PMTs and SiPMs
- Emission spectrum measured with spectrograph
- BC-408 and PS similar yields, use BC-408 as reference
- Excited by monochromatic 380 nm light
- Drawback: limited absorption length

# Emission Spectra Results



Emission Spectra of PEN, BC-408 and PMMA tiles ( $30 \times 30 \times 3$  mm<sup>3</sup>)

- Blue emission from PEN
- Lower yield than BC-408




PEN exposed to UV

- Measured emission spectrum from wavelength shifting, not scintillation
- Can PEN shift VUV?
- 126 nm light from LAr source
- Compare efficiency of tile coated with TPB and PEN



# Wavelength Shifting Results



Left: Ratio of PMT anode currents (blue line) PEN/TPB Right: VUV/UV emission spectrum of liquid argon [arXiv:1511.07718]

- Efficiency of wavelength shift around 50% of TPB at 126 nm
- Optically active without scintillation
- Enhanced efficiency of liquid argon vetoes
- Consistent with DEAP: arXiv:1806.04020



Raw PEN Granulate

- Low-background experiments need low-background material
- Commercially available PEN granulate gamma screened at LNGS
- Two types: TN8050, TN8065
- Reference measurement: GERDA HV-capacitor [arXiv:1903.10736]

# Radiopurity Results

	TN-8065S	TN-8050SC	Teonex Q51 [Eur. Phys. J. C (2013) 73:2445] [mBq/kg]
Ra-228	< 0.15	< 0.15	
Th-228	(0.23 ± 0.05)	< 0.13	< 1.4
Ra-226	(0.25 ± 0.05)	< 0.11	< 2.0
Th-234	< 11	< 15	
Pa-234m	< 3.4	< 3.0	
U-235	< 0.066	< 0.054	
K-40:	1600 ± 400	1000 ± 400	< 3.6
Cs-137	< 0.057	< 0.064	

Measurement by M. Laubenstein (68 % C.L.)

- Commercially available pellets have comparable counts to materials in use
- Surface contamination
- Reduce levels in PEN by synthesis



- GERDA currently employs active background rejection to improve signal to noise ratio
- Multi-phase approach, muon veto, water Cherenkov tagging and liquid argon
- Efficiency for current argon veto is not very high
- PEN is a commercially available plastic, relatively radiopure
- Both scintillates and wavelength shifts
- Emission peak suitable for many photo-detectors
- Scintillation yield lower than other plastics, attenuation limits part size
- Demonstrated to wavelength shift liquid argon peak emission to blue